


4. GUARDS

4.2. PG GUARDS



PGH J INNER GUARD HALVES: SERIES P (POWER DRIVE) FOR P DRIVE SHAFTS

The same guard half is also used for the PWE drive shaft with SPGF guard on the P joint side

Guards	D	n ¹⁾	LI	Drawing No.	Part No.
	[mm]		[mm]		
PGH20	185	5	1000	86.201	1116127
PGH20	185	5	1500	86.201	1116622
PGH30	230	8	1000	86.301	1116130
PGH30	230	8	1500	86.301	1116437

¹⁾ n = number of ribs